

HOW TO ORDER NEEDLE VALVES

PART NUMBER



INLET & OUTLET CODES

Select M or F for Male or Female

03 M or F = 1/4" NPT	04 M or F = 1/4" BSPP	13 M or F = 1/4" BSPTaper
05 M or F = 3/8" NPT	06 M or F = 3/8" BSPP	14 M or F = 3/8" BSPTaper
07 M or F = 1/2" NPT	08 M or F = 1/2" BSPP	15 M or F = 1/2" BSPTaper
09 M or F = 3/4" NPT	10 M or F = 3/4" BSPP	16 M or F = 3/4" BSPTaper
11 M or F = 1" NPT	12 M or F = 1" BSPP	17 M or F = 1" BSPTaper

MATERIAL CODES

AI = AISI 316 S/S	HA = HASTELLOY
MO = MONEL	IN = INCOLOY 825
BR = BRASS	TI = TITANIUM

AMBIT Instruments Pty Ltd

PO Box 8138 Carrum Downs Vic 3201 Freecall 1800 101 102 (Aust)

Fax 03 97766 8888